

# POLI-TRANS DESIGN YOUR OWN SHIRT

## GENERAL USE

**INKJET LIGHT** can be used in most ink jet printers. Produce high resolution transfers for application to light and pastel textiles. Transfers can be applied to cotton, polyester and poly/cotton textiles. Easy to apply giving a **soft and high quality** result.

Always single sheet feed transfer papers. Allow the ink to dry and do not apply until 10 minutes after printing.

## PRINTER SETTINGS

In general we suggest the printer settings are set to plain paper and fine or photo quality. Settings on printers vary, therefore produce a test print to determine the best settings.

## APPLICATION

Print selected image on the blank side of the transfer paper - **mirror image**. Trim around the design with scissors. Pre-heat T-shirt to remove moisture - 3 to 4 seconds.

- Press at 175 °C (350 Fahrenheit)
- Time 15 sec.
- Heavy pressure
- Remove transfer immediately (hot peel)

### Tips

- After pressing, gently pull each side of the T-shirt, this will pull up a corner for easy release
- After the transfer has been removed, stretch the t-shirt in both directions. This helps to give a soft feel

## WASHING

- Textiles should be machine washed inside out up to 40 degrees
- Do not tumble dry, dry clean or iron directly over transfer