

# POLI-TRANS® 310 INKJET DARK A4

## **GENERAL USE**

**INKJET DARK** can be used in most ink jet printers. Produce high resolution transfers for application to dark coloured textiles. Transfers can be applied to cotton, polyster and poly/cotton textiles. **INKJET DARK** can also be contour cut using a vinyl cutter.

Always single sheet feed transfer papers. Allow the ink to dry and do not apply until 10 minutes after printing.

#### **PRINTER SETTINGS**

In general we suggest the printer settings are set to plain paper and fine or photo quality. Settings on printers vary, therefore produce a test print to determine the best settings.

### APPLICATION

Print selected image on the blank side of the transfer paper, do not mirror image. To avoid showing white areas when applied to the T-shirt, trim around the design. Use a vinly cutter, with low force, to cut around complex shapes. Remove backing paper and position design on T-shirt. Always cover the transfer with silicone paper during heat press application.

- Press at 160 °C (320 Fahrenheit)
- Time 20 sec.
- Medium pressure
- Remove silicone paper cold
- Not suitable for textiles dyed with sublimation inks

## WASHING

- Textiles should be machine washed inside out in a cool wash only
- Do not tumble dry, dry clean or iron directly over transfer

All information given is for guidance purposes only. Many different factors are involved in producing transfers, therefore we recommend customers to perform their own tests. These instructions are not legally binding. Information given is subject to change without notice.